

TYPE C ADAPTER

AVVERTENZE:

Leggere tutte le istruzioni e gli avvertimenti prima di utilizzare questo prodotto. L'uso improprio di questo prodotto può causare danni, surriscaldamento, fumi tossici, incendio o esplosione, per i quali danni è responsabile l'Acquirente e non il Produttore.

La sicurezza di questo prodotto è garantita con l'uso delle seguenti istruzioni, pertanto è necessario conservarle per un utilizzo futuro.

- Non esporre il caricatore alla pioggia, all'umidità, a qualsiasi prodotto liquido o a muffe.
- Non immergere in un liquido.
- Solo per uso interno.
- Non esporre alla polvere, ai raggi diretti del sole, a forte calore e ad impatti meccanici.
- Per la pulizia esterna utilizzare solo un panno morbido, pulito e leggermente umido.
- L'uso di detergenti e/o solventi può danneggiare il prodotto in modo irreversibile.
- Questo prodotto non è un giocattolo. Tenerlo fuori dalla portata dei bambini e degli animali domestici.
- Non lasciare incustodito il materiale di imballaggio. Potrebbe trasformarsi in un pericoloso giocattolo per i bambini.
- Nel caso in cui il prodotto si presenti danneggiato non utilizzarlo, rivolgersi ad un centro di assistenza autorizzato.

TYPE C ADAPTER

WARNING:

Read all instructions and warnings prior to use this product. Improper use of this product may result in product damage, excess heat, toxic fumes, fire or explosion, for which damages Purchaser and not Manufacturer is responsible.

The safety of this product is guaranteed by observing the following instructions, so it is necessary to keep them safe for future use.

- Do not expose the charger to rain, moisture, any liquid product, or mould.
- Do not immerse in any liquid.
- Only for indoor use.
- Do not expose to dust, direct sunlight, strong heat, or any mechanical force.
- Use only a soft, clean, and slightly damp cloth for cleaning the outside.
- The use of detergents and/or solvents can damage the product irreversibly.
- This product is not a toy.
Keep it out of the reach of children and pets.
- Do not leave the packaging material unattended. It could become a dangerous plaything for children.
- If the product is damaged, do not use it. Consult an authorised service centre.

