



## **ASSEMBLYINSTRUCTIONS**ISTRUZIONI DI MONTAGGIO

Ax1	Bx5		Cx1	Dx1
Ex2	Fx1		Gx1	Hx1
lx1	Jx1		Kx1	Lx1
IL IR		JL JR		
Mx8	Nx4	Rx4	Ox12	Px1 Qx4
<b>⊕</b> <b>M8*25mm</b>	<b>M8*30mm</b>	<b>●</b> → M5*12mm		





