



ODYSSEY AURICOLARI




ISTRUZIONI D'USO


AVVERTENZE:

- Leggere attentamente il seguente manuale e conservarlo per utilizzi futuri.
- L'esposizione prolungata a suoni di volume troppo elevato può provocare danni permanenti all'udito. Regolare il volume a un livello appropriato.
- Non utilizzare il prodotto durante attività di guida, corsa, ciclismo o dove è necessario mantenere attenzione elevata all'ambiente esterno.
- Non utilizzare durante il sonno.
- Non utilizzare il prodotto per scopi diversi da quelli per cui è stato costruito. L'impiego del prodotto per usi diversi da quelli consentiti può dar luogo a situazioni di pericolo.
- Solo per uso domestico.
- Tenere lontano da contatto con acqua e non immergere in liquidi.
- Non esporre a polvere, luce solare diretta o forte calore.
- Non manomettere o riparare autonomamente il prodotto, potrebbe causare danni irreversibili.
- Non utilizzare se danneggiato.
- Non utilizzare detergenti chimici per pulire il prodotto, utilizzare solo un panno morbido e asciutto.
- Questo prodotto non è un giocattolo. Tenere fuori dalla portata dei bambini e di animali domestici. Piccole parti possono causare soffocamento e lesioni.

FUNZIONI MUSICA:



FUNZIONI CHIAMATA:



SPECIFICHE TECNICHE:

Modello	In-ear
Spina	Type-C
Potenza massima in ingresso	5mW
Speaker	14.5mm
Gamma di frequenza	20 Hz ~ 20 kHz
Sensibilità	11±63dB
Impedenza	32Ω±20%
Lunghezza cavo	1,2 m

INFORMAZIONI AGLI UTENTI

Ai sensi del Decreto Legislativo N°49 del 14 marzo 2014 "Attuazione della Direttiva 2012/19/EU sui rifiuti di apparecchiature elettriche ed elettroniche (RAEE)". Il simbolo del cassonetto barrato riportato sull'apparecchiatura indica che il prodotto alla fine della propria vita utile deve essere raccolto separatamente dagli altri rifiuti. L'utente dovrà, pertanto, conferire l'apparecchiatura integra dei componenti essenziali giunta a fine vita agli idonei centri di raccolta differenziata dei rifiuti elettronici ed elettrotecnici, oppure riconsegnarla al rivenditore al momento dell'acquisto di una nuova apparecchiatura aventi lato maggiore inferiore a 25cm. L'adeguata raccolta differenziata per l'avvio successivo dell'apparecchiatura dimessa al riciclaggio, al trattamento e allo smaltimento ambientale compatibile contribuisce ad evitare possibili effetti negativi sull'ambiente e sulla salute e favorisce il riciclo dei materiali di cui è composta l'apparecchiatura. Lo smaltimento abusivo del prodotto da parte dell'utente comporta l'applicazione delle sanzioni amministrative di cui al D.Lgs n. Decreto Legislativo N°49 Marzo 2014.



©2022 AAAmaze® is a registered trademark. Device produced for AAAmaze® by Smart Sales Srl - Via Isonzo 36, 21055 Gorla Minore (VA), Italy. All trademarks belong to their respective owners.



ODYSSEY EARBUDS




INSTRUCTIONS


WARNINGS:

- Please read this owner's guide carefully and save it for future reference.
- Prolonged exposure to loud music may cause permanent damage to your hearing. Adjust volume to an appropriate level.
- Do not use this product while driving, running, bicycling, or where you need to remain alert to your surroundings.
- Do not use while sleeping.
- Do not use the product for purposes other than those for which it was manufactured. Use of the product for other than its intended purpose may result in hazardous situations.
- Only for domestic use.
- Keep away from contact with water and do not immerse in liquids.
- Do not expose to dust, direct sunlight or strong heat.
- Do not tamper with or repair the product yourself, it may cause irreversible damage.
- Do not use if damaged.
- Do not use chemical cleaners to clean the product, use only a soft, dry cloth.
- This product is not a toy. Keep out of reach of children and pets. Small parts may cause choking and injury.

MUSIC FUNCTIONS:



CALL FUNCTIONS:



TECHNICAL SPECIFICATIONS:

Model	In-ear
Plug	Type-C
Max Power Input	5mW
Speaker	14.5mm
Frequency Range	20 Hz ~ 20 kHz
Sensitivity	11±63dB
Impedance	32Ω±20%
Cable Length	1,2 mt

INFORMATION FOR USERS

Pursuant to Legislative Decree N°49 of 14 March 2014 "Implementation of Directive 2012/19/EU on waste electrical and electronic equipment (WEEE)". The crossed-out bin symbol shown on the equipment indicates that the product at the end of its useful life must be collected separately from other waste. The user must, therefore, deliver the equipment complete with essential components at the end of its life to the appropriate separate collection centers for electronic and electrical waste, or return it to the retailer at the time of purchase of new equipment of an equivalent type, in the ratio of one to one, or 1 to zero for equipment with a longer side of less than 25cm. Adequate separate collection for the subsequent start-up of the discarded equipment for recycling, treatment and environmentally compatible disposal helps to avoid possible effects negative on the environment and on health and favors the recycling of the materials of which the equipment is made. Illegal disposal of the product by the user involves the application of administrative sanctions pursuant to Legislative Decree no. Legislative Decree N°49 of 14 March 2014.



AMAT0011
MADE IN CHINA
AAA
MAZE

©2022 AAAmaze® is a registered trademark. Device produced for AAAmaze® by Smart Sales Srl - Via Isonzo 36, 21055 Gorla Minore (VA), Italy. All trademarks belong to their respective owners.